

Technical Data Sheet

LAVO Natural Wall Paper Paste No. 535

N means **LIVOS neutral** for the allergy-prone and chemically sensitive

Range of application	In the interior, for light and medium heavy wallpapers like woodchip wallpaper. Only to a limited extent suitable for painter's fleece and non-woven wallpapers (see also page 2). Not suitable for vinyl-foam wallpapers. Also suitable for handicrafts.
Technical qualities	High adhesive power, good wet strength, good correction possibility (relocatability). Temperature variation resistant, easy to stir, easy to apply. Can be mixed homogeneously with water. Easy to remove and smooth.
Full declaration	Methylcellulose. Without preservatives.
Color	Transparent.
Application method	Paste wallpapers evenly, then fold up and leave to soak. Afterwards wallpaper.
Coverage	Average consumption 9g per m ² , depending on absorbency.
Cleaning	Clean tools immediately after use with cold water.
Drying time	According to the coating thickness, temperature and humidity 12- 24 hours.
Safety advice	P 102 Keep out of the reach of children. Avoid generation of dust!
Disposal	According to locally regulated laws.
Container sizes	0.2 kg; 0.5 kg.
Storage	Store cool, dry and tightly closed. Shelf life: unopened at least 5 years. Use mixed Wall Paper Paste within 24 hours. See reverse for application instructions.

How to use

LAVO Natural Wall Paper Paste No. 535

General Surface requirements

Surfaces must be smooth, dry, clean, stable and moderately absorbent.

Preparation

Clean walls and ceilings thoroughly. Remove old wallpapers. Close cracks and holes with VEDO Wall Filler No. 440. Pre-paste strong absorbent surfaces with LAVO Natural Wall Paper Paste No. 535 (mix with 1:36). Prime slightly sandy plaster with GRAVA Wall Primer Sealer No. 408.

Approach

Stir package content into cold water (see table). Stir again after 2-3 minutes. After approximately 30 to 45 minutes stir strongly one-time: LAVO Natural Wall Paper Paste is now ready for use.

Mixing tables for 0,5 kg LAVO Natural Wall Paper Paste No. 535

Intended purpose	Mixture	Water in liter	Coverage
Pre-paste	1 : 36	18	140 m ²
Woodchip wallpaper and structural wallpaper	1 : 25	12.5	60 m ²

Application

Paste wallpapers evenly, then fold up and leave 5 - 10 minutes to soak. Afterwards wallpaper. Dab or wash off residues of paste from the front immediately and carefully with a sponge and clear water.

Important Tips

Non-woven wallpapers and painter's fleeces have different compositions and absorbencies. Therefore, the suitability and the coverage must be tested. The paste is applied directly to the wall and the fleece is placed on top.

For use as wallpaper change primer, dilute GRAVA Wall Primer Sealer No. 408 with 20% water and mix this solution with LAVO Natural Wall Paper Paste No. 535 in a ratio of 1:1.

Nicotine and water stains can be blocked by priming with REMIO Natural Stain Blocking Primer No. 618. Chipboard, plywood and OSB – boards as well as substrates that contain penetrating substances should be primed with REMIO No. 618 as well. If you use REMIO there is no need to use GRAVA. In case of salt efflorescence, a professional has to determine the type of efflorescence and to find a remedy before sealing measures are taken.

These directions are the result of long years of research and practical testing. They are backed by our most current expert information. New findings may invalidate this information. The latest version is available on our website at www.livos.de. This data sheet is meant to serve as information and instruction. No legal liability should be interpreted from it. In case of doubt, please contact the LIVOS customer service (see page 1).

February 2023